

SELFGUARD Generator Auto Start Auto Stop Unit with Remote (GSU-2) is an auto-start, auto-stop unit with remote for all types of self-start generators.

In **Auto mode**, the generator starts automatically after the absence of the main supply and stops automatically after the presence of the main supply.

In **Manual mode**, the generator can be started with the green/start button present on the main unit or the remote unit, and the generator can be stopped by pressing the red/stop button on the main unit or remote unit anytime in the absence of the main supply. The generator will also stop automatically after the presence of the main supply if not stopped with the red/stop button.

In either **Auto or Manual mode**, the unit stops the generator automatically when the main supply is present.

The **remote** unit provided with the main unit can be operated with a 4-core wire having a thickness of 0.5mm only from an unlimited distance. With the remote unit, you can remote start and remote stop the generator, and the Auto and Manual modes can also be changed remotely.

Safety Feature: This unit will not bypass any Safety of the Generator.

This PDF provides information on the **Item Code: GSU-2 (For Cummins)**.

This Model is compatible with all the Generators of **Cummins/Sudhir/Jakson** that starts with **both Key and Push Button**.

*Connection Diagram is Provided with unit.

*You can also find the Connection Diagram here: [Selfguard GSU-2 \(For Cummins\) Connection Diagram](#)

SELFGUARD Generator Auto Start Auto Stop Unit with Remote (GSU-2) comes in four different models, depending on the connection of the unit with different types of generators. The working of all four models is the same.

*Find the Complete range of **Generator Auto Start Auto Stop Unit (GSU-2)** here: [Selfguard GSU-2 All Models](#)

Another compatible Model:

Now, start your generator from up to 300 feet with the ease of **wireless remote** using

Generator Auto Start Auto Stop Unit with Wireless Remote (For Cummins) Item Code: GSU-2W (For Cummins)

in place of **GSU-2 (For Cummins)**.

Find the complete Product details at: [Selfguard GSU-2W \(For Cummins\) Product Details](#)



Functions
Remote Start – Remote Stop
Remote Start – Auto Stop
Auto Start – Auto Stop

