



Rating (In Amps.)	63 Amps.	100 Amps.	150 Amps.	200 Amps.
SIZE (L*B*H) In mm	300*250*115	450*310*135	450*310*135	450*310*135

**SELFGUARD Three Phase Automatic Changeover Switch (CTF)** transfers the load automatically from mains to generator and from generator to mains.

This Unit will be installed between **Three Phase Mains Supply** and **Single Phase Generator** or **Three Phase Generator**.

**During the absence of Main Supply when the Generator starts**, this unit automatically shifts the load to Generator side.

**After the Presence of Main Supply**, this unit shifts the load from Generator to Mains without any delay and Generator runs on No Load Condition.

**This Product is Applicable for** Three Phase Main Supply and Single Phase Load only (such as Lights, Fans, Single Phase AC, Single Phase Motors etc.)

**The selection of Changeover** is done according to the load of Main Supply.

\*Find the Connection Diagram here: [Selfguard CTF Connection Diagram](#)

For Three Phase Load (such as Three Phase Lift, Three Phase AC, Three Phase Motor), Please install **Selfguard Automatic Transfer Switch (CTSD)**. Find the Complete Details at: [Selfguard CTSD Product Details](#)

\*Find the Complete range of **Automatic Changeover Switch ((CSNF), (CTF) and (CTSD))** here: [Selfguard Automatic Changeover All Models](#)