

Item Code: WLC-FP

(for submersible panel equipped with a starting capacitor, and green and red push buttons)



SELFGUARD Fully Automatic Water Level Controller (FP) is used to start the motor automatically when the water level in the tank drops below the minimum level and stop the motor automatically when the tank is filled to the maximum level.

This Water Level Controller is suitable for submersible panel equipped with a starting capacitor, and green and red push buttons.

A toggle switch is provided to switch ON and OFF the water level controller.

This Unit comes with Plastic Magnetic Float Sensors that are Rust Proof in all types of water.



Technical Specifications	
Operating Voltage	150 to 250 Volts A.C.
Frequency	50 Hz
Current Rating	~30 Amps.
No. of Sensors used	2
For Motor Rating	Upto 2 HP

*Find the Complete range of Water Level Controller (WLC) here: [Selfguard WLC All Models](#)